

L-V22 Wall mounted soap dispenser

Lovair L-V22 soap dispenser is a pump action wall mounted soap dispenser with 1000ml capacity.



Operation

The lever on the front is depressed by the user, which releases a measured amount of soap from the dispenser onto the user's hands.

Stainless Steel Version

The soap dispenser is made from AISI 304 type stainless steel in either a brushed satin or mirror polished finish.

Maintenance

The dispenser should be inspected periodically to check that no damage has occurred and that the cover can still be opened for refilling.

Cleaning

All grades of stainless steel will stain or discolour if due care and attention is not taken. The surface must be regularly cleaned to ensure a long service life of the dispenser.

Use a soft cloth or sponge with a mild solution of soapy water as part of the regular washroom janitorial routine. Do not use abrasive or cream cleaners as these will damage the surface finish.

If the dispenser is subjected to a highly chlorinated environment eg swimming pools or marine coastal locations, a further treatment, in addition to the regular cleaning as described above, is recommended by the application of a household cleaning product containing silicone.

White Steel Version

The dispenser is made from white painted mild steel. Regular cleaning and inspection is necessary to prevent corrosion and ensure a long service life.

Maintenance

The dispenser should be inspected periodically to check that no damage has occurred and that the cover can still be opened for refilling.

Cleaning

Use a soft cloth or sponge with a mild solution of soapy water as part of the regular washroom janitorial routine. Do not use abrasive or cream cleaners as these will damage the surface finish.

If the surface finish becomes scratched or chipped, then the exposed metal should be treated with an appropriate proprietary surface finish to prevent any corrosion starting.

Soap

A good quality liquid soap of viscosity 100 – 3800 cPs units should be used. Hand cleaners containing abrasive particles should not be used as this will cause damage to the pump mechanism.

Lovair recommend the range of hand soaps available from Selden Research. Visit www.selden.co.uk for further details.

Refilling

1. The key is $\frac{1}{4}$ turned and the cover is then hinged forward.
2. Soap can then be poured in to the reservoir, and the cap replaced.
3. The cover can now be closed and locked.
4. The dispenser should now be operated to ensure that soap is dispensed.

The level of soap should be checked regularly to ensure that there is sufficient in the dispenser to allow soap to be released. This would normally be part of the janitorial routine.

The soap dispensers contain no user-servicable parts.

If further information is required, contact Lovair technical team for more detailed care guidelines.

Lovair Los Angeles

5450 W. 83rd Street T +1 (310) 410 5008
Los Angeles CA90045

Lovair UK

Pavilion View, Newby Rd T +44 (0) 161 482 7000 technical@lovair.com
Stockport SK7 5DA F +44 (0) 161 482 7050 lovair.com