

L-140 L140 Series deck mounted sensor tap



Codes		
L-141 L-142		
No. on picture	Description	Part code
2,3	Sensor kit (includes o-ring seal)	L07220041
1	Grub screw - to secure spout to mounting spigot	L230103
7,8,9	Solenoid valve housing & connection nipple	L07221119
7,8,9,10,11	Solenoid valve including housing & connection nipple	L130044
10	Solenoid valve diaphragm only	L04500001
10,11	Solenoid kit inc diaphragm	L7500002
15	Flexi-hose - 450mm	L09510053
15	Flexi-hose - 700mm	L09510073
12	Fixing nut	L240004
13	Fixing washer	-
6	Rubber sealing washer	-
5	O-ring	-
14	Fixing boss	-
16	Aerator - Cascade flow 4lpm (1 Gal/min)	L08510040
Not pictured	Flexi hose connector (to aerator) - fits behind aerator	L130005
17	Battery box - IP67	L260025
18	Transformer - IP68	L06522101
Optional accessories		
Not pictured	Low pressure solenoid valve, housing and nipple	L130004
16	Aerator - Spray flow 4lpm (1 Gal/min)	L08510037
16	Aerator - Spray flow 1.89lpm (0.5 Gal/min)	L08510012
16	Aerator - Pearlator flow 6lpm	L08510034
16	Aerator - Spray flow 3lpm	L130048
16	Aerator - Spray flow 1.3lpm (0.35 Gal/min)	L130001
Not pictured	Battery back-up device - IP67	L06530033
Not pictured	Powersplitter - 2 way	L06001012
Not pictured	Powersplitter - 3 way	L06001008
Not pictured	Extension cable - 1 metre	L06009016
Not pictured	Extension cable - 4 metres	L06009032

